

NEW YORK WIRE
DOORWAY SCREEN CURTAIN

NO TOOLS REQUIRED!



Let the fresh air in!

Great for anywhere you need a screen door.



Stronger ideas for a sustainable world



Economical alternative to a screen door

The Doorway Screen Curtain is a weighted fiberglass mesh curtain that can be hung in doorway openings. It allows you to enjoy fresh air in the house, patio, camper or RV while minimizing the presence of bothersome flying pests like bees, moths, mosquitoes and flies.

It's a collapsible temporary screen door without the inconvenience or expense of a permanent screen door installation. You can enjoy fresh outside air in less than five minutes. No tools are required to install the doorway screen curtain – simply twist to adjust the tension rod to fit the doorway opening. This system is simple to use and reuse, season after season.

Features and benefits of the Doorway Screen Curtain include:

- Attaches to any door frame
- Adjustable tension rod provides easy installation, removal and reuse
- No tools required
- Curtain is constructed from heavy-duty fiberglass engineered for maximum durability, but also folds for easy storage
- Weighted bottom allows the screen to hang straight in light breezes even when it's not fastened to the sides of door frame

Each package includes: 38"W x 81"H Doorway Screen Curtain, adjustable mounting rod, hook and loop fasteners and easy-to-follow instructions.



Installation Instructions



1

Twist to adjust the size of the tension rod to the width for the doorway. It should be adjusted to be slightly larger than the door frame to enable the tension rod's inner spring to hold the rod in place

against the door frame. For best results, test for proper sizing by positioning the rod into the door frame to check its holding power. The tension rod fits doorways up to 38" wide.



2

Slide the tension rod into the pocket at the top of the screen curtain.

Center and gather the screen so that both of the rubber-tipped ends of the tension rod protrude from each side of the pocket.



3

Push the tension rod into place at the top of the door frame. Holding the tension rod at an angle, press firmly against one side of the door frame to compress the tension rod slightly. Slide the opposite

end of the tension rod into place while allowing the tension rod to decompress and hold the curtain in place. Adjust position up or down as needed.



4

For greater insect protection, attach screen to the door frame at the top and sides using adhesive hook & loop tabs. Simply peel the back off the self-adhesive hook & loop tabs and adhere

them to the door frame in a position that matches the tabs on the screen curtain. Press the hook & loop tabs together firmly to attach the doorway screen curtain to the sides of the door frame.

PART #	COLOR	SIZE	WEIGHT (lb.)	PRODUCT UPC
FSP8509-U	Charcoal	38" x 81	1.98	011646729736

PART #	CASE COUNT	UNITS/PALLET	CASE DIMENSIONS (in.) LxWxH	CASE WEIGHT (lb.)	CASE UPC
FSP8509-U	4	352	24.5x5x6.5	7.93	10011646729733

▶ Visit www.newyorkwire.com to learn more about our products, view our how-to videos and our screen selector tool to make sure you have the right screen for your needs.

www.adfors.com

SAINT-GOBAIN ADFORS America, Inc.
1795 Baseline Road
Grand Island, NY 14072
USA
Phone: 800-762-6694
Fax: 716-775-3902

Follow us on:



www.newyorkwire.com

1717 2/15